


## Setting the buffer low to facilitate drip feed in Windows 2000 Professional.

Follow pictures step by step. Click where mouse pointer is shown.



| System Properties  | ? X |  |  |  |  |  |  |
|--|-----|--|--|--|--|--|--|
| General Network Identification Hardware User Profiles Advanced   |     |  |  |  |  |  |  |
| Hardware Wizard  | - 1 |  |  |  |  |  |  |
| The Hardware wizard helps you install, uninstall, repair,<br>unplug, eject, and configure your hardware.   |     |  |  |  |  |  |  |
| Hardware Wizard  |     |  |  |  |  |  |  |
| Device Manager   |     |  |  |  |  |  |  |
| The Device Manager lists all the hardware devices installed<br>on your computer. Use the Device Manager to change the<br>properties of any device. |     |  |  |  |  |  |  |
| Driver Signing Device Manager  |     |  |  |  |  |  |  |
| Hardware Profiles  |     |  |  |  |  |  |  |
| Hardware profiles provide a way for you to set up and store different hardware configurations.   |     |  |  |  |  |  |  |
| Hardware Profiles  |     |  |  |  |  |  |  |
|  |     |  |  |  |  |  |  |
| OK Cancel Apply  |     |  |  |  |  |  |  |





| Communications Port (COM1) Properties  | <u>?</u> × |
|--|------------|
| General Port Settings Driver Resources |            |
| Bits per second: 9600                  | 3          |
| Data bits: 8                           | 3          |
| Parity: None                           | ]          |
| Stop bits: 1                           | ]   [      |
| Flow control: None                     | ]          |
| Advanced Restore Defau                 | ılts       |
|  |            |
| OK Can                                 | cel        |

| Advanced Settings for COM  |              |                  |   |  |      | <u>?×</u>    |
|--|--------------|------------------|---|--|------|--------------|
| Use FIFD buffers (red<br>Select lower settings<br>Select higher settings | o correct co | nnection problem |   |  |      | OK<br>Cancel |
| Receive Buffer: Low (1)  |              | , .              |   | —————————————————————————————————————— | (14) | Defaults     |
| Transmit Buffer: Low (1)   | 1            | ı                | ı | ——— Ü High (16)                        | (16) |              |
| COM Port Number: COM1  | •            |                  |   |  |      |              |

| Advanced Settings for COM1                          |   |       |                        |     | ?×           |
|---|---|-------|------------------------|-----|--------------|
|   | ires 16550 compatible UART)<br>correct connection problems.<br>or faster performance. |       |                        |     | OK<br>Cancel |
| Receive Buffer: Low (1)<br>Transmit Buffer: Low (1) | ₽<br>₽  | · · · | High (14)<br>High (16) | (1) | Defaults     |
| COM Port Number: COM1                               | Y .   | • •   | nign (10)              |     |              |